

Directions For Setting Up Your Take-It-Easel

1 Unwrap the narrow strap from around the easel along with the canvas support pegs. Remove the hooked rod and extender leg from stored position.

6 Insert hooked rod into one of the top holes angled to reduce glare on your painting surface. Use a bungee cord to secure it in windy conditions or to hold small works, replacing the hooked rod.

4 Unhook twin support bars from the top of the rear leg. Let the copper-clad holder slide all the way down to the rear leg, allowing the twin support bars to spread and drop into the desired notches on the crossbar. To make the easel rigid, slide the copper clad holder forward slightly as a tensioner.

5 Place the canvas support pegs into the front legs at the desired height.

3 Drop down the wide cross bar from the right leg and insert it into the bracket on the left leg.

2 Pull the spring lever to full tension toward your palm and slide each leg out to desired height releasing the lever into its relaxed position. Be sure leg spring snaps into the hole, especially in storage to ensure good spring tension for the life of the easel.

For extremely uneven terrain the extender leg pegs plug into the bottom holes on any leg.

extender leg

